


INTERCHANGE SHIM. TO CAMPY old system

This manual can be used for these hubs:
 from F172SB to F272SB
 from F162SB to F262SB
 from F372SB to F472SB



Shim. & Campy left & right side caps are different !
 Shim. left side cap compare to Campy is longer.
 Shim. right side cap compare to Campy is shorter.




Insert allen key to axle and hold it.
 Unscrew right side cap by wrench key
 by anti-clockwise direction.



Remove Shim. Cassette body.




Remove Shim. right side cap.



Remove CrMo spacer.

INTERCHANGE SHIM. TO CAMPY old system



Step 05

Hold allen key & unscrew left side cap by wrench key by anti-clockwise direction.



Step 10

Insert Campy cassette body to axle.



Step 06

Remove Shim. left side cap.



Step 11

Insert Campy side cap to axle.




Step 07

Insert Campy left side cap.




Step 12

By wrench key tight Campy right side cap by clockwise direction.



Step 08

Hold allen key & by wrench key tight Campy left side cap by clockwise direction.



Step 09

Insert CrMo spacer back to axle.



Shim. & Campy side caps are different !